

AVAILABLE DOOR SIZES

SMOOTH SURFACE MOLDED DOORS

	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
Craftsman III™																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	C	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	C	X	X
Madison®																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	C	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	C	X	X
8'0" Smooth				X	X	X	X	X	X	X	X	X	X	X	C	X	X
Rockport®																	
6'8" Smooth					X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth								X	X	X	X	X	X	X	CB	X	X
8'0" Smooth					X	X		X	X	X	X	X	X	X	CB	X	
Conmore®																	
6'8" Smooth					X	X		X	X	X	X	X	X	X	S	X	X
7'0" Smooth					X	X		X	X	X	X	X	X	X	S	X	X
Carrara®																	
6'8" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
8'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
Cambridge™																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
8'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
Princeton™																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
8'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
Caiman®																	
6'8" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
8'0" Smooth					X	X		X	X	X	X	X	X	X	CB		
Continental™																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
8'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
Cashal®																	
6'8" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
8'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
Santa Fe™																	
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
7'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
8'0" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
Corvado®																	
6'8" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
8'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
Coventry®																	
6'8" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
7'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X
8'0" Smooth	X	X	X	X	X	X		X	X	X	X	X	X	X	CB	X	X

Sticking Profile: B=Beaded, CB=Cove and Bead, C=Craftsman, S=Stepped Sticking, O=Ovolo

SMOOTH SURFACE MOLDED DOORS (CONTINUED)

Colonist®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Smooth	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
7'0" Smooth					X	X	X	X	X	X	X	X	X	X	CB	X	X
8'0" Smooth					X	X	X	X	X	X	X	X	X	X	CB	X	X

TEXTURED SURFACE MOLDED DOORS

Camden®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
7'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
Avalon®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
7'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
Provincial®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
7'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
Colonist®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
7'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
8'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	CB	X	X
Colonial™	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
7'0" Textured	X	X	X	X	X	X	X	X	X	X	X	X	X	X	O	X	X
8'0" Textured					X	X	X	X	X	X	X	X	X	X	O	X	X

Sticking Profile: B=Beaded, CB=Cove and Bead, C=Craftsman, S=Stepped Sticking, O=Ovolo

MIRROR MOLDED DOORS

Impression™ Mirror	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured								X		X	X	X		X	O		

WIDE-STILE* LIGHT COMMERCIAL DOORS

Colonial™	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Textured														X	O	X	
7'0" Textured														X	O	X	
Colonist®	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Smooth														X	CB	X	
7'0" Smooth														X	CB	X	
Continental™	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Smooth														X	O	X	
7'0" Smooth														X	O	X	
Cambridge™ Beaded	1'0"	1'2"	1'3"	1'4"	1'6"	1'8"	1'10"	2'0"	2'2"	2'4"	2'6"	2'8"	2'10"	3'0"	Sticking Profile	ProCore®	Bifolds
6'8" Smooth														X	B	X	
7'0" Smooth														X	B	X	

Sticking Profile: B=Beaded, CB=Cove and Bead, C=Craftsman, S=Stepped Sticking, O=Ovolo

* Assuming standard bore machining (2-1/8" diameter bore), outer stile measurements listed above must be no less than 3-3/4" in order to accommodate a 2-3/8" backset on the lock hole. For 2-3/4" backsets, outer stile measurements must be no less than 3-13/16". If lock bore machining is less than the outer stile measurements listed above, all lock bore drilling must be done within the lock rail for best appearance and performance. Outer stile dimension may vary 1/4" from the measurements listed above.